
List of figures

Figure 1	
Trunk cards in the Meridian 1 architecture	5
Figure 2	
IPE trunk cards installed in an NT8D11 CE/PE Module	12
Figure 3	
IPE trunk cards installed in an NT8D37 IPE Module	13
Figure 4	
PE trunk cards installed in an NT8D13 PE Module	14
Figure 5	
Network connections to PE/IPE modules	17
Figure 6	
Typical IPE trunk card architecture	18
Figure 7	
DS-30X loop data format	21
Figure 8	
Typical PE trunk card architecture	23
Figure 9	
SL-1 Network loop data format	25
Figure 10	
Typical trunk interface unit block diagram	26
Figure 11	
Universal trunk card—faceplate	32
Figure 12	
Universal trunk card—block diagram	33

Figure 13	
Loop start call states—incoming call from CO/FX/WATS	37
Figure 14	
Loop start call connection sequence—incoming call from CO/FX/WATS	38
Figure 15	
Loop start call states—outgoing call to CO/FX/WATS	39
Figure 16	
Loop start call connection sequence—outgoing call to CO/FX/WATS	40
Figure 17	
Ground start call states—incoming call from CO/FX/WATS	42
Figure 18	
Ground start call connection sequence—incoming call from CO/FX/WATS	43
Figure 19	
Ground start call states—outgoing call to CO/FX/WATS	45
Figure 20	
Ground start call connection sequence—outgoing call to CO/FX/WATS	46
Figure 21	
DID trunk, loop DR call states—incoming call from CO	48
Figure 22	
DID trunk, loop DR call connection sequence—incoming call from CO	49
Figure 23	
Two-way, loop DR, tie trunk call states—incoming call from far-end PBX	50
Figure 24	
Two-way, loop DR, tie trunk call connection sequence—incoming call from far-end PBX	51
Figure 25	
Two-way, loop DR, tie trunk call states—outgoing call to far-end PBX	52
Figure 26	
Two-way, loop DR, tie trunk call connection sequence—outgoing call to far-end PBX	53

Figure 27	
Two-way, loop DR, tie trunk call states—incoming call through senderized, tandem PBX from a CO/FX/WATS trunk	55
Figure 28	
Two-way, loop DR, tie trunk call states—outgoing call through far-end PBX to CO/FX/WATS	56
Figure 29	
Two-way, loop OAID, tie trunk call states—incoming call from far-end PBX	58
Figure 30	
Two-way, loop OAID, tie trunk call connection sequence—incoming call from far-end PBX	59
Figure 31	
Two-way, loop OAID, tie trunk call states—outgoing call to far-end PBX	60
Figure 32	
Two-way, loop OAID, tie trunk call connection sequence—outgoing call to far-end PBX	61
Figure 33	
Connecting RAN equipment to the NT8D14 Universal Trunk Card (typical)	63
Figure 34	
RAN control signals (Control GRD = IDLE)	64
Figure 35	
Universal trunk card—typical cross connect example	72
Figure 36	
Universal trunk card—jumper locations (for NT8D14BB release 10 and higher)	76
Figure 37	
Universal trunk card—jumper locations (for NT8D14BA, NT8D14BB release 9 and below)	77
Figure 38	
Connecting paging equipment to the NT8D14 Universal Trunk Card (typical)	81

Figure 39	
E&M trunk card—faceplate	85
Figure 40	
E&M trunk card—block diagram	86
Figure 41	
E&M Type I signaling	89
Figure 42	
E&M Type II signaling	89
Figure 43	
4-wire DX signaling	90
Figure 44	
Paging trunk operation	91
Figure 45	
Signaling orientation for tandem connection between E&M and CO trunks	
95	
Figure 46	
E&M Type I signaling patterns—originating party release	96
Figure 47	
E&M Type I signaling patterns—originating party release on a tandem	
connection	97
Figure 48	
E&M Type II signaling patterns—originating party release	99
Figure 49	
E&M Type II signaling patterns—originating party release on a tandem	
connection	100
Figure 50	
E&M trunk card—typical cross connection example	110
Figure 51	
E&M trunk card—jumper locations	112
Figure 52	
Pad orientation	116
Figure 53	
Paging trunk operation	117

Figure 54	
E&M/DX and paging trunk card—faceplate	121
Figure 55	
E&M/DX and paging trunk card—block diagram	122
Figure 56	
E&M lead signaling patterns, originating party release	128
Figure 57	
E&M lead signaling patterns, originating party release on tandem connections	129
Figure 58	
E&M/DX and paging trunk card—typical cross connection example .	138
Figure 59	
E&M/DX and paging trunk card—switch locations	141
Figure 60	
Pad switching algorithm	143
Figure 61	
Simplified schematic of DX bridge signaling/E&M signaling and paging interface	144
Figure 62	
Simplified schematic of DX bridge signaling circuit	145
Figure 63	
Schematic showing paging system connections	147
Figure 64	
Recorded announcement trunk card—faceplate	150
Figure 65	
Recorded announcement trunk card—block diagram	151
Figure 66	
RAN control signals	156
Figure 67	
Recorded announcement trunk card—typical cross connection example	160
Figure 68	
Recorded announcement trunk card—switch and jumper locations . .	163

Figure 69	
4-wire E&M/DX card—faceplate	175
Figure 70	
4-wire E&M/DX trunk card block diagram	176
Figure 71	
Type I interface	178
Figure 72	
Type II interface	179
Figure 73	
Back-to-back circuit connection	179
Figure 74	
Type I (British Post Office) interface	180
Figure 75	
E&M lead Type I signaling patterns—originating party release (when route does not involve a CO/FX/WATS trunk)	185
Figure 76	
E&M lead Type I signaling patterns—originating party release on tandem connections when originating end is senderized and route is through a CO/ FX/WATS trunk (not applicable to CCSA lines)	186
Figure 77	
E&M lead Type II signaling patterns—originating party release (when route does not involve a CO/FX/WATS trunk)	187
Figure 78	
E&M lead Type II signaling patterns—originating party release on tandem connections when originating end is senderized and route is through a CO/ FX/WATS trunk (not applicable to CCSA lines)	188
Figure 79	
Simplified schematic diagram of a DX signaling (4-wire) circuit for the QPC237A/B	189
Figure 80	
Simplified schematic diagram of a DX signaling (4-wire) circuit for the QPC237C	190

Figure 81	
Simplified schematic diagram of a DX signaling (4-wire) circuit for the QPC237D	191
Figure 82	
4-wire E&M/DX trunk card—typical cross connection example	199
Figure 83	
4-wire E&M trunk card—switch locations	201
Figure 84	
Recorded telephone dictation trunk card—faceplate	207
Figure 85	
Recorded telephone dictation trunk card—block diagram	208
Figure 86	
Out-of-service lead circuit	211
Figure 87	
K1 and K2 relay operation	212
Figure 88	
Seizure and dial pulsing	214
Figure 89	
Talking connection	214
Figure 90	
Answer supervision	215
Figure 91	
Recorded telephone dictation trunk card—typical interconnections ..	221
Figure 92	
Recorded telephone dictation trunk card—switch locations	223
Figure 93	
Release link trunk card—faceplate	226
Figure 94	
Release link trunk card—block diagram	227
Figure 95	
Release link trunk card—typical cross connection example	236

Figure 96	
Release link trunk card—switch and jumper settings	238
Figure 97	
Loop signaling trunk card—faceplate	241
Figure 98	
Loop signaling trunk card—block diagram	242
Figure 99	
Loop signaling trunk card—typical cross connection example	253
Figure 100	
Loop signaling trunk card—switches and jumpers	256
Figure 101	
Pad switching algorithms	257
Figure 102	
CO/FX/WATS trunk card—faceplate	260
Figure 103	
CO/FX/WATS trunk card—block diagram	261
Figure 104	
Metering pulse operation	266
Figure 105	
Ground start trunk incoming call connection sequence	268
Figure 106	
Ground start trunk outgoing call connection sequence	269
Figure 107	
Near end (Meridian 1) disconnects first	270
Figure 108	
Far end (CO) disconnects first	271
Figure 109	
Loop start trunk incoming call connection sequence	272
Figure 110	
Loop start trunk outgoing call connection sequence	273
Figure 111	
CO/FX/WATS trunk card—typical cross connection example	277

Figure 112	
CO/FX/WATS trunk card—switch and jumper settings	280
Figure 113	
Pad switching algorithm	287

